



<b>Item no.</b>	<b>Description</b>	<b>Article no.</b>	<b>Quantity</b>
1	Aluminum handle	61135	1
2	Joint shaft	61136	1
3	Joint shaft	61103	1
4	Joint shaft	61104	1
5	Y bracket	61137	1
6	M8 circlip for joint shaft M8	F82480	3
7	Piston	61138	1
8	O-ring	61107	2
9	Main valve housing	61108	1
10	Screw main valve housing	61109	4
11	Plastic caps	61139	8
12	Screw	61111	4
13	Main bracket	61112	1
14	Brass fitting	61113	1
15	Rubber ball $\text{Æ}$ 9,5	1300000132	2
16	Non returning valve	61141	1
17	Non returning valve housing I.D. $\text{Æ}$ 6	61118	1
18	Brass union I.D. $\text{Æ}$ 6	61119	1
19	Ball valve	61142	1
20	Valve housing	61121	1
21	Valve wheel	61122	1
22	Gauge	R6112300	1
23	Hose	R6112500	1
24	PVC-grip	61127	1
25	Plastic tank	61128	1
26	Screw	61143	2
27	Coil spring	61131	1
28	Grease nipple	H98963	1
29	Handle	61133	1
30	ROTHENBERGER Label	61134	1
31	Manometer sealing ring R 1/4"	H98987	1

**IMPORTANT!** To assure safety and reliability, repairs, maintenance and adjustment must be preformed by ROTHENBERGER Kelkheim or authorized Service-Centers. Always use Original-Service-Parts. Order your accessories and spare parts from your specialist retailer or using our Service After Sales hotline